

## Example




**1. Wind direction:** NW



**2. Barometer reading (sea level):** 987mb



**3. Barometer:** Falling  
**Period:** S Summer



**4. Code letter:** X  
**Forecast:** Rain, very

# Pocket Weather Forecaster



Create your own  
accurate local forecast

## HOW TO USE

1. Rotate the clear disc so that the arrow marked Set Wind is aligned with the current wind direction, as marked on the outer edge of the main brass dial.
2. Holding the clear disc in place, rotate the smaller, central brass disc so that the arrow marked Set to Barometer Reading is set to the current barometer reading (corrected to sea level if barometer not adjusted for altitude).
3. Depending on whether the barometer is Rising, Falling or Steady, read a code letter from the appropriate window. The letters S and W are further refinements, making allowance for seasonal variation. Summer being taken from April to September inclusive, and Winter from October to March.
4. Refer to the back of the forecaster for an interpretation. Forecasts are for 12 hours and the best time to take a forecast is 9am.

*When new, please remove clear protective film from brass discs before use.*